


## T6620B1008

### Digital Room Thermostat

# DT200


42010474-001 R2




Installation • Instalación • Installasjon • Installatie • Installazione • Telepítés • Montáž • Instalacja • Inštalácia

<p><b>1</b></p>	<p><b>2</b></p>	<p><b>3</b></p>
<p><b>4</b></p>	<p><b>5</b></p> <p><b>a</b> 24-240 V~ 50/60 Hz &lt;math&gt;&lt;8(3)A&lt;/math&gt; T6620 A B C N L</p> <p><b>b</b> 24-240 V~ 50/60 Hz &lt;math&gt;&lt;8(3)A&lt;/math&gt; T6620 A B C N L T1 T2</p> <p><b>c</b> 24-240 V~ 50/60 Hz &lt;math&gt;&lt;8(3)A&lt;/math&gt; T6620 A B C N L BL BR B R Z100...G.</p> <p><b>d</b> 24-240 V~ 50/60 Hz &lt;math&gt;&lt;8(3)A&lt;/math&gt; T6620 A B C N L GY BL BR GR O L N V4043</p> <p><b>e</b> 24-240 V~ 50/60 Hz &lt;math&gt;&lt;8(3)A&lt;/math&gt; T6620 A B C N L M6</p> <p><b>f</b> 24-240 V~ 50/60 Hz &lt;math&gt;&lt;8(3)A&lt;/math&gt; T6620 A B C N L max. 1.5 kW</p>	
<p><b>6</b></p>	<p><b>7</b></p> <p>2. RESET</p>	<p><b>8</b></p>

- GB** Room Temperature
- E** Indicación de temperatura ambiente
- F** Lecture de la température ambiante
- NL** Uitlezing van de ruimtetemperatuur
- D** Raumtemperatur-Istwert
- I** Lettura temperatura ambiente
- HU** Aktuális helyiséghőmérséklet
- CZ** Aktuální pokojová teplota
- PL** Odczyt temperatury
- SR** Izbová teplota



- GB** Set Temperature, Inquiry
- E** Consulta de temperatura de consigna
- F** Lecture de la température demandée
- NL** Uitlezing van de ingestelde temperatuur
- D** Eingestellte Temperatur abfragen
- I** Interrogazione temperatura impostata
- HU** Beállított hőmérséklet lekérdezése
- CZ** Dotaz na nastavenou teplotu
- PL** Odczyt temperatury zadanej
- SR** Informácia o teplote



- GB** Set temperature, adjustment
- E** Selección del punto de consigna
- F** Réglage de la température demandée
- NL** Wijziging van de ingestelde temperatuur
- D** Eingestellte Temperatur ändern
- I** Modifica temperatura impostata
- HU** Kívánt hőmérséklet beállítása
- CZ** Nastavení požadované teploty
- PL** Ustawianie temperatury zadanej
- SR** Nastavenie požadovanej teploty

